


# Where is everything?

## Sharp Aquos 70" Monitor and Dell 9020 Mini Computer



### Switching between inputs:

- Press the TOUCH MENU button (3) to display the Input Menu shown to the right
- Choose the appropriate input. The 303 rooms are already set up with the following inputs:
  - Whiteboard (digital whiteboard interface)
  - DisplayPort PC1 (the Dell Mini Computer attached to the back of the screen—must be turned on separately)
  - HDMI1 COMPONENT (AirMedia which allows a laptop's screen to display on the Sharp Aquos monitor)

